1. Before Installing

Ensure that you have:

- ✓ AudioCodes Fax ATA, model MP-202B **HTTPSFAX**
- ✓ Included 12V power adapter (use only the one supplied for your country)
- ✓ Local network (LAN) with DHCP and Internet connection
- ✓ Fax Machine or fax-capable MFP

YOUR FAX SOLUTION

The Fax ATA can be connected to either online service providers or to premise-based fax servers. You may have received additional steps or separate instructions with your Fax ATA so please check with your specific provider or fax server manager before proceeding.

CREATE YOUR ACCOUNT

Depending on what fax provider or fax solution to which you are connecting your Fax Machine, you may have to first create your account. Refer to your provider supplied instructions that came with the Fax ATA or their web site for additional steps or details.

FaxCONNECTit If you are connecting your Fax Machine through FaxCONNECTit to your own fax service provider account, make sure you sign up and create your account before continuing at: www.faxconnectit.com.


⚠️ **CHECK FAX MACHINE SETTINGS**

Turn off your Fax Machine's success notifications. Your fax provider or premise-based fax server will automatically send delivery notifications to your Fax Machine or directly to you via email.

If you are going to be receiving faxes at your Fax Machine, set your fax machine to auto-answer by default. Some Fax Machines do not retain this setting after being turned on or restarted.

---

2. Connecting

1. Connect the Ethernet Connector labeled **"WAN"** to your network.

Power

Network Connection in **WAN** Port

Do **NOT** use LAN/PC for network connection

2nd Fax Machine (optional)

Fax Machine

2. Connect the Telephone Port labeled **PHONE 1** to the Fax Machine. Check with your provider whether the second PHONE 2 port is enabled for use.

3. Connect the Power. There is no ON/OFF (I/O) switch so the Fax ATA turns on as soon as you connect the power. The **POWER** LED is lit (green) and when initialization completes (~1 minute), the **STATUS** LED changes from red to green.

Getting Help: Go to www.faxata.com for additional help and documentation.

⏰ **INITIALIZATION**

Wait for all 3 status lights to go green. Usually within a minute, however could be more than 5 minutes if an automatic upgrade is needed and can also vary depending on your Internet speed.

3. Activating

Before you can send faxes, you will need to activate your Fax ATA. Refer to specific instructions supplied by your provider or fax server manager. **Note:** Connections to some service provider connections and premise-based fax servers may not require activation.

To activate your Fax ATA, follow the steps below.

1. Make sure you have your **PIN** for activation. This is supplied by your provider or fax server administrator.
2. You activate the Fax ATA from your Fax Machine or MFP.
3. Go off-hook and dial the following:

   1<PIN>#   (for example, dial ***1*1234#**)
4. Press SEND or START if your Fax Machine requires this step to start dialing.
5. You will hear an audio confirmation once the activation is complete.

4. Send a Fax

You can now send a fax from your Fax Machine.

Getting Help: Go to www.faxata.com for additional help and documentation.

AudioCodes CPE & Access Gateway Products

MP-20x series MediaPack™ Series Telephone Adapters with Integrated Router

Fax ATA
MP-202B HTTPS Fax Adapter

Quick Installation Guide

LTRT-041-HTTPSFAX

HTTPS FAX

![AudioCodes Connecting Networks]